

PAD MOUNTED TRANSFORMER CONNECTION CHART

**THREE PHASE TRANSFORMER
MAXIMUM NUMBER OF CONNECTIONS***

| <u>SERVICE VOLTAGE</u> | <u>KVA</u> | <u>MAX. CONN. W/O CTs</u> | <u>MAX. CONN. W/ CTs</u> |
|------------------------|------------|-------------------------------|------------------------------|
| 208/120 | 75 | 6 | 4 |
| 208/120 | 150 | 6 | 4 |
| 208/120 | 300 | 8 | 6 |
| 208/120 | 500 | 10 | 8 |
| 208/120 | 750 | 10 | 8 |
| 208/120 | 1500 | 10 | 8 |
| 480/277 | 75 | 6 | 4 |
| 480/277 | 150 | 6 | 4 |
| 480/277 | 300 | 10 | 8 |
| 480/277 | 500 | 10 | 8 |
| 480/277 | 750 | 10 | 8 |
| 480/277 | 1000 | 10 | 8 |
| 480/277 | 1500 | 10 | 8 |
| 480/277 | 2000 | 12 | 12 |
| 480/277 | 3000 | 12 | 12 |

*** AVAILABLE STOCK MAY DICTATE NUMBER OF CONNECTIONS; CONFIRM WITH YOUR STAKING TECHNICIAN**